

Autopsy

Sreekanth N



Agenda

- Introduction
- Features
- Screenshots
- Demo
- Results
- Conclusion
- References

Introduction

- **Digital Forensics**
- Autopsy
- Digital forensics is the scientific examination and analysis of data held on, or retrieved from, computer storage media in such a way that the information can be used as evidence in a court of law.



Introduction

- **Digital Forensics**

- Autopsy

- Digital forensics activities commonly include:
 - the **secure** collection of computer data
 - the **identification** of suspect data
 - the **examination** of suspect data to determine details such as origin and content
 - the **presentation** of computer-based information to courts of law
 - the **application** of a country's laws to computer practice.




Introduction

- Digital Forensics
 - **Autopsy**
- Autopsy is an easy to use, GUI-based program that allows you to efficiently analyze hard drives and smart phones. It has a plug-in architecture that allows you to find add-on modules or develop custom modules in Java or Python.
- It can analyze Windows and UNIX disks and file systems (NTFS, FAT, UFS1/2, Ext2/3, etc.).




Features


- Multi-User Cases: Collaborate with fellow examiners on large cases.
- Timeline Analysis: Displays system events in a graphical interface to help identify activity.
- Keyword Search: Text extraction and index searched modules enable you to find files that mention specific terms and find regular expression patterns.
- Web Artifacts: Extracts web activity from common browsers to help identify user activity.
- Registry Analysis: Uses RegRipper to identify recently accessed documents and USB devices.
- LNK File Analysis: Identifies short cuts and accessed documents
- Email Analysis: Parses MBOX format messages, such as Thunderbird.




Features

- Media Playback and Thumbnail viewer.
- Robust File System Analysis: Support for common file systems, including NTFS, FAT12/FAT16/FAT32/ExFAT, HFS+, ISO9660 (CD-ROM), Ext2/Ext3/Ext4, Yaffs2,
- Unicode Strings Extraction: Extracts strings from unallocated space and unknown file types in many languages
- File Type Detection based on signatures and extension mismatch detection.
- Interesting Files Module will flag files and folders based on name and path.
- Android Support: Extracts data from SMS, call logs, contacts, Tango, Words with Friends, and more.





Screenshots



Listing

Table

Thumbnail

Data Sources

- 8-peg-search.dd
 - \$OrphanFiles (0)
 - \$CarvedFiles (3)
 - \$Extend (5)
 - \$Unalloc
 - alloc
 - ar (3)
 - del1 (3)
 - del2 (3)
 - invalid (5)
 - misc (6)
 - RECYCLER (
 - System Volume Information (3)
- Views
- Results
 - Extract
 - Extension Mismatch Detected (2)
 - Keyword Hits
 - Single Literal Keyword Search (0)
 - Single Regular Expression Search (0)
 - Hashset Hits
 - E-Mail Messages
 - Interesting Items

New Case Information

Steps

1. Case Information
2. Optional Information

Case Information


Case Name:

Base Directory:

Browse

Case Type: ☒ Single-user ☐ Multi-user

Case data will be stored in the following directory:



Listing

Table

Thumbnail

Data Sources

8-jpeg-search.dd
 \$OrphanFiles (0)
 \$CarvedFiles (3)
 \$Extend (5)
 \$Unall
 all
 arc (5)
 del1 (3)
 del2 (3)
 invalid (5)
 misc (6)
 RECYCLER (3)
 System Volume Information (3)

Views

Results

Extra

E

Keyword Hits

Single Literal Keyword Search (0)

Single Regular Expression Search (0)

Hashset Hits

E-Mail Messages

Interesting Items

Accounts

Tags

New Case Information

Steps

1. Case Information
2. **Optional Information**

Optional Information

Case

Number:

Examiner

Name:

Phone:

Email:

Notes:

Organization

Organization analysis is being done for:



Manage Organizations

< Back

Next >

Finish

Cancel

Help



3

Add Data Source

Steps

1. **Select Type of Data Source To Add**
2. Select Data Source
3. Configure Ingest Modules
4. Add Data Source

Select Type of Data Source To Add



Disk Image or VM File



Local Disk



Logical Files



Unallocated Space Image File



Add Data Source

Steps

1. Select Type of Data Source To Add
- 2. Select Data Source**
3. Configure Ingest Modules
4. Add Data Source

Select Data Source

Browse for an image file:

C:\Users\Sreekanth\Desktop\image files\8-jpeg-search\8-jpeg-search.dd

Browse

Please select the input timezone: (GMT+5:30) Asia/Calcutta

☐ Ignore orphan files in FAT file systems

(faster results, although some data will not be searched)

Sector size: Auto Detect

4



Listing

Data Sources

Data Sources

Views

Results

Extracted Content

Keyword Hits

Single Literal Keyword Search (0)

Single Regular Expression Search (0)

Hashset Hits

E-Mail Messages

Interesting Items

Accounts

Tags

Reports

Add Data Source

Steps

1. Select Type of Data Source To Add
2. Select Data Source
3. **Configure Ingest Modules**
4. Add Data Source

Configure Ingest Modules

Run ingest modules on:

All Files, Directories, and Unallocated Space

- ☒ Recent Activity
- ☒ Hash Lookup
- ☒ File Type Identification
- ☒ Embedded File Extractor
- ☒ Exif Parser
- ☒ Keyword Search
- ☒ Email Parser
- ☒ Extension Mismatch Detector
- ☒ E01 Verifier
- ☒ Encryption Detection
- ☒ **Interesting Files Identifier**
- ☒ PhotoRec Carver
- ☒ Correlation Engine
- ☒ Virtual Machine Extractor

Select interesting files sets to enable during ingest:

Identifies interesting items as defined by interesting item rule sets.

Identifies interesting items as defined by interesting item rule sets.

Select All

Deselect All

History

5

Results?





Listing

By Extension

Table Thumbnail

File Type

File Extensions








 Images (3)	.jpg, .jpeg, .png, .psd, .nef, .tiff, .bmp, .tec, .tif
 Videos (0)	.aaf, .3gp, .asf, .avi, .m1v, .m2v, .m4v, .mp4, .mov, .mp...
 Audio (0)	.aiff, .aif, .flac, .wav, .m4a, .ape, .wma, .mp2, .mp1, .mp...
 Archives (2)	.zip, .rar, .7zip, .7z, .arj, .tar, .gzip, .bzip, .bzip2, .cab, .j...
 Databases (0)	.db, .db3, .sqlite, .sqlite3
 Documents	'htm', '.html', '.doc', '.docx', '.odt', '.xls', '.xlsx', '.ppt', '.ppt...
 Executable	'exe', '.msi', '.cmd', '.com', '.bat', '.reg', '.scr', '.dll', '.ini'

Data Sources

- 8-jpeg-search.dd
 - \$OrphanFiles (0)
 - \$Extend (5)
 - \$Unalloc (1)
 - alloc (4)
 - archive (5)
 - del1 (3)
 - del2 (3)
 - invalid (5)
 - misc (6)
 - RECYCLER (3)
 - System Volume Information (3)

Views

File Types

- By Extension
 -  Images (3)
 -  Videos (0)
 -  Audio (0)
 -  Archives (2)
 -  Databases (0)
 -  Documents
 -  Executable
- By MIME Type
- Deleted Files
- MB File Size

Hex Strings Application Indexed Text Message File Metadata Results Annotations Other Occurrences

- Important Links - Hexeditor <https://mh-nexus.de/en/hxd/>

Assignments

- Download SuspectData.dd file from folder SuspectData and explore the same using autopsy.
- Ensure you name your folder in the following format example 001-M-DJD-S
- Inside that folder you must have the following folders
 - Autopsy - Inside this your autopsy files should go
 - Docs - maintain a txt file with the artifact name. That text file should maintain time stamps of all that you do.
 - Images – Make sure you create a folder Exhibit001 and inside that the image that you received/ created using some imaging sft (FTK Imager)
 - Reports - The reports that you generate should be in this folder
 - Temp – Temporary data should be here
- Maintain all the records anything interesting that you find accordingly

References

- <https://www.sleuthkit.org/autopsy/>
- <https://www.autopsy.com/>
- [https://en.wikipedia.org/wiki/Autopsy_\(software\)](https://en.wikipedia.org/wiki/Autopsy_(software))
- <https://resources.infosecinstitute.com/category/computerforensics/introduction/free-open-source-tools/autopsy-forensics-platform-overview/#gref>

Thank you

danke
nandri
takk
grazie
hvala
gracias
dziękuję
dėkuji
kiitos
Xièxiè
спасибо
ευχαριστώ
mahalo
tānan
dank u
gràcies
tack
köszönöm
благодаря
shukran
teşekkür ederim
dhanyavād
faleminderit
hвала
erima kasih
merci
diolch
agodaram
Bakujem
Баярлалаа
paldies
giyabonga
thoukrane
tak
obrigado
ačiū
shukran
teşekkür ederim
dhanyavād
faleminderit
hвала
erima kasih
merci
diolch
agodaram
Bakujem
Баярлалаа
paldies
giyabonga
thoukrane
tak
obrigado
ačiū
shukran
teşekkür ederim
dhanyavād
faleminderit
hвала
erima kasih

arigatō
감사합니다
Mh'gōi
תודה